CHROMA/STENCIL REMOVER 285

CHOMA/STENCIL REMOVER™ 285

Chroma/Stencil Remover™ 285 is a super concentrated liquid product formulated for the removal of all photosensitized emulsions. Especially suitable for automatic systems.

APPLICATION

Chroma/Stencil Remover 285 should be diluted with clean water, at a ratio of 1 part product to 20-40 parts water. Chroma/Stencil Remover 285 contains additives to aid in the complete removal of photosensitized emulsions from all types of screen mesh.

CHARACTERISTICS

Chroma/Stencil Remover 285 is a water-soluble colorless liquid with no flash point. Product contains some acid solutions and therefore is classified as corrosive. Chroma/ Stencil Remover 285 quickly and easily dissolves all photosensitized emulsions and rinses away completely.

USEAGE INSTRUCTIONS

For manual application, apply the Chroma/Stencil Remover 285 solution to both sides of the wet screen. Allow solution to dissolve the emulsion. Scrub the stencil area on both sides to aid in a more complete removal of the stencil. Rinse with high pressure water. No degreasing usually required, except when applying capillary films.



FOR TECHNICAL SERVICE

Call Toll Free: 1-800-328-4261 Email: help@chromaline.com

(Outside North America Call +1-218-628-2217)

To ensure the safe and proper use of Chroma/Screen Chemical products, always refer to the products of SDS before use.











