

BLAZER ORANGE

BLASTABLE LASER MASK

INSTRUCTIONS

1. Unroll desired size.
2. Apply the laser mask to the side of the substrate that is to be laser ablated and blasted.
3. Squeegee out the air bubbles and wrinkles.
4. Remove the polyester carrier by flicking one edge of the carrier to loosen and then peel.
5. Laser through the film to create your sandblastable mask. Please use the suggested laser settings below as a reference point. These settings will vary depending on laser wattage, speed, and artwork.
6. Sandblast to desired depth up to 1/16th*. Color fill or finish as desired.
7. For removal of the film, simply peel or soak in water.

**For a deeper etch, try one of IKONICS Imaging's other quality photo resist films.*



BLAZER ORANGE

BLASTABLE LASER MASK

XL

INSTRUCTIONS

1. Unroll desired size, remove slipsheet.
2. Apply the laser mask to the side of the substrate that is to be laser ablated and blasted.
3. Squeegee out the air bubbles and wrinkles.
4. Remove the polyester carrier by flicking one edge of the carrier to loosen and then peel.
5. Laser through the film to create your sandblastable mask. Please use the suggested laser settings below as a reference point. These settings will vary depending on laser wattage, speed, and artwork.
6. Sandblast to desired depth, up to 1/16th. Color fill or finish as desired.
7. For removal of the film, simply peel or soak in water.

**For a deeper etch, try one of IKONICS Imaging's other quality photo resist films.*



USER'S GUIDE